



LMR for UGM

RF RECEIVER READER

17,3 cm antenna Wave $\lambda/4$
or antenna of 50Ω

Channel configuration :

Place jumper according to
the channel which should
be activated.

