




# CONTACT BADGE READER FOR UGA/2

## WIRING

Contact badge reader :



1. Connection to the UGA2 control unit:

Reader outputs	Door A UGA2 input	Door B UGA2 input
-	<b>M</b>	<b>J</b>
+	<b>N</b>	<b>I</b>